

2 manual 11 rank Wurlitzer Theatre Pipe Organ Marrickville Town Hall

Pedal		Accomp		Solo	
Resultant (Bourdon)	32	English Horn	8	English Horn (Ten C)	16
Tuba Profunda	16	Harmonic Tuba	8	Tuba Profunda	16
Diaphone	16	Diaphonic Diapason	8	Diaphone	16
Tibia Clausa	16	Tibia Clausa	8	Tibia Clausa	16
Bourdon	16	Clarinet	8	Clarinet (Ten C)	16
English Horn	8	Strings II	8	Krumet (Ten C)	16
Harmonic Tuba	8	Concert Flute	8	Orchestral Oboe (TC)	16
Open Diapason	8	Vox Humana	8	Strings II (Ten C)	16
Tibia Clausa	8	Tibia Piccolo	4	Bourdon	16
Clarinet	8	Strings II	4	Vox Humana (Ten C)	16
Cello	8	Flute	4	English Horn	8
Flute	8	Vox Humana	4	Harmonic Tuba	8
		Twelfth	2 2/3	Open Diapason	8
Pedal Back Rail		Piccolo	2	Tibia Clausa	8
		Harp		Clarinet	8
Piano*	16/8	Chrysoglott		Krumet	8
Bass Drum				Orchestral Oboe	8
Kettle Drum		Accomp Second Touch		Strings II	8
Crash Cymbal		English Horn	8	Concert Flute	8
Cymbal Roll		Harmonic Tuba	8	Vox Humana	8
Cymbal		Open Diapason	8	Tibia Quint	5 1/3
Accomp to Pedal		Clarinet	8	Octave Diapason	4
Solo to Pedal		Tibia Piccolo	4	Tibia Piccolo	4
		Cathedral Chimes		Strings II	4
		Octave Glockenspiel		Flute	4
		Triangle		Tibia Twelfth	2 2/3
				Tibia Piccolo	2
		Accomp Back Rail		Fifteenth	2
		Snare Drum		Piccolo	2
		Tambourine		Tierce (Tibia or Flute)	1 3/5
		Castanets		Fife (Tibia or Flute)	1
		Chinese Block		Harp	
		Tom Tom		Chrysoglott	
		Cymbal (Choke)		Xylophone	
		Piano*	8	Glockenspiel	
		Accomp Octave			
				Solo Back Rail	
				Flute Select	
				Piano*	8
				Piano*	4
				Cathedral Chimes	
				Sleigh Bells	
				Sub Octave	
				Unison Off	
				Octave	

<p>Tremulants</p> <p>Main (Clarinet, Diapason, Flute) Strings Solo (Krumet, Orch Oboe) Tibia & Vox Tuba</p> <p>Celeste Off Percussion Re-it (affecting Xylophone, Glockenspiel)</p> <p>Swell Pedals</p> <p>Solo, Main, General, Crescendo</p> <p>Toe Pistons (8)</p> <p>1 – 5 Combinations Toe Pistons (cont'd)</p> <p>6,7,8 Traps (alterable)</p>	<p>Left Toe Lever</p> <p>1st touch – Snare Drum 2nd touch – Bass Drum & Crash Cymbal</p> <p>Right Toe Lever</p> <p>1st touch – Sforzando (Solo manual 16' stops) 2nd touch – 8' stops & glockenspiel</p> <p>Key cheek Buttons</p> <p>Fire gong, Horse hooves, Bird, Surf, Boat whistle, Doorbell, Pistol shot, Auto horn</p> <p>15 Combination pistons plus cancel piston per manual General cancel piston</p>
---	---

Ten C = no pipes below tenor C.

Strings II = Salicional & Voix Celeste

Select Flute changes Tierce & Fife from Tibia to Flute. Piano not yet connected.